

Reset auf Werkseinstellungen AVR-3808-4308

Schalten Sie dazu das Gerät mit dem Netzschalter aus (nicht die Standby Taste) (siehe auch untenstehende Anleitung) drücken Sie die Standard und DSP Simulation Taste gleichzeitig und schalten Sie das Gerät wieder ein. Das Display beginnt zu blinken, lassen Sie die beiden Tasten wieder los und versuchen Sie erneut das Gerät mit dem Netzwerk zu verbinden.

CAUTION IN SERVICING

Initializing AV SURROUND RECEIVER

AV SURROUND RECEIVER initialization should be performed when the μ com, peripheral parts of μ com, and Digital P.W.B. are replaced.

1. Switch off the unit.
2. Hold the following STANDARD button and DSP SIMULATION button, and switch on the unit.
3. Check that the entire display is flashing with an interval of about 1 second, and release your fingers from the 2 buttons and the microprocessor will be initialized.

Note: • If step 3 does not work, start over from step 1.
• All user settings will be lost and this factory setting will be recovered when this initialization mode. So make sure to memorize your setting for restoring after the initialization.

